


303520



Switch insert (1 pole)

Description	Pack qty.	Art No.
Rockers switch for shutters inserts	10	303520



382120



Key switch

Description	Pack qty.	Art No.
KEY SWITCH FLUSH-MOUNT.	10	382120
KEY SWITCH FLUSH-MOUNTING	10	383120
KEY SWITCH FLUSH MOUNTING	10	383620
KEY SWITCH CH.OV.FLUSH	10	385620



1861

Accessories

Description	Pack qty.	Art No.
ARRESTING DISC	10	1861