

# HRC fuse carriers

Fuse carriers allow to protect and control circuits against overloads and short circuits.



LS401

## 1 pole

Description	Pack	Art No.
Fuse carrier 1P 25A L31 1M	12	<b>LS401</b>
Fuse carrier 2P 25A L31 2M	6	<b>LS402</b>
Fuse carrier 3P 25A L31 3M	4	<b>LS403</b>
Fuse carrier 3P+N 25A L31 4M	3	<b>LS404</b>
Fuse carrier 1P+N 25A L31 2M	6	<b>LS412</b>
Fuse carrier 1P 25A L31 signal light 1M	12	<b>LS431</b>



LS501

## 2 pole

Description	Pack	Art No.
Fuse carrier 1P 32A L38 1M	12	<b>LS501</b>
Fuse carrier 2P 32A L38 2M	6	<b>LS502</b>
Fuse carrier 3P 32A L38 3M	4	<b>LS503</b>
Fuse carrier 3P+N 32A L38 4M	3	<b>LS504</b>
Fuse carrier 1N 32A L38 1M	12	<b>LS509</b>
Fuse carrier 1P+N 32A L38 2M	6	<b>LS512</b>
Fuse carrier 1P 32A L38 signal light 1M	12	<b>LS531</b>
Fuse carrier 1P+N 32A L38 1M	12	<b>L50600</b>



LS601

## 3 pole

Description	Pack	Art No.
Fuse carrier 1P 50A L51 acc. 1.5M	Qty.	<b>LS601</b>
Fuse carrier 2P 50A L51 acc. 3M	1	<b>LS602</b>
Fuse carrier 3P 50A L51 acc. 4.5M	1	<b>LS603</b>
Fuse carrier 3P+N 50A L51 acc. 6M	1	<b>LS604</b>
Fuse carrier 1P+N 50A L51 acc. 3M	1	<b>LS612</b>
Fuse carrier 1P 50A L51 1.5M	10	<b>LR601</b>
Fuse carrier 2P 50A L51 3M	5	<b>LR602</b>
Fuse carrier 3P 50A L51 4.5M	3	<b>LR603</b>
Fuse carrier 3P+N 50A L51 6M	2	<b>LR604</b>
Fuse carrier 1P+N 50A L51 3M	5	<b>LR612</b>



LS701

## 4 pole

Description	Pack	Art No.
Fuse carrier 1P 125A L58 acc. 2M	Qty.	<b>LS701</b>
Fuse carrier 2P 125A L58 acc. 4M	1	<b>LS702</b>
Fuse carrier 3P 125A L58 acc. 6M	1	<b>LS703</b>
Fuse carrier 3P+N 125A L58 acc. 8M	1	<b>LS704</b>
Fuse carrier 1P+N 125A L58 acc. 4M	1	<b>LS712</b>
Fuse carrier 1P 125A L58 2M	6	<b>LR701</b>
Fuse carrier 2P 125A L58 4M	3	<b>LR702</b>
Fuse carrier 3P 125A L58 6M	2	<b>LR703</b>
Fuse carrier 3P+N 125A L58 8M	1	<b>LR704</b>
Fuse carrier 1P+N 125A L58 4M	3	<b>LR712</b>



LS670

## Accessories

Description	Pack	Art No.
Microswitch 1P for fuse carrier L51	Qty.	<b>LS670</b>
Microswitch 3P for fuse carrier L51	1	<b>LS671</b>
Microswitch 1P for fuse carrier L58	1	<b>LS770</b>
Microswitch 3P for fuse carrier L58	1	<b>LS771</b>



LS672

## Signal lights 230 V

Description

Signal light 230V fuse carrier L51/L58

Pack Art No.

Qty. **LS672**