


3031

Rocker switch insert


Description	Pack qty.	Art No.
rocker switc on/off Module insert	10	3031
Change-over switch 10AX 250V~	10	3036
rocker switc intermediate Module insert	10	3037
SWITCH FOR INSERTS	10	303212
MOD-EINS WIPPSCHALTER M RD TR 10AX 250V~	10	303601
Change-over switch for installation in h	10	303650
Change-over switch for installation in h	10	613036
Rocker switch w/ground terminal contact	10	52303213



3035

2-Rockers switch insert


Description	Pack qty.	Art No.
Rockers switch Module inserts	10	3035
Series switch for installation in hollow	10	303550



633023

3-Rockers switch insert


Description	Pack qty.	Art No.
Rockers switch Module inserts	10	633023



5031

Rocker push button insert

Description	Pack qty.	Art No.
Rocker push-butto NO contact Module ins	10	5031
Rocker push-button Module inserts	10	5036
Rocker push-button Module inserts	10	503101
Push-button, NO contact for installation	10	503150
MOMENTARY CONTACT SWITCH	10	503203




5035

2-Rockers push button insert

Description	Pack qty.	Art No.
Rockers push-button Module inserts	10	5035
Group rockers push-butto 4 NO, common i	10	503404
Rockers push-button Module inserts	10	503501
Rockers push-button for blind 1pole Mod	10	503520
Rockers push-button Module inserts	10	503808

Pullcord switch


Description	Pack qty.	Art No.
PULLCORD SWITCH	10	3966
PULLCORD CHANGE-OVER SW.	10	390640
PULLC.PUSHB.SW.M2 PW	10	395619



3966

Key switch

Description	Pack qty.	Art No.
KEY SWITCH	10	382210
KEY SWITCH CHANGE-OVER	10	382610
KEY SWITCH 1POLE	10	383110
KEY SWITCH 2POLE	10	383210



382210

Hotel Card switch


Description	Pack qty.	Art No.
COVER F. CARD SW. TP PW	10	164109
COVER F.HOTEL SW. TP BLAC	10	164165



164109

Push button insert for HotelCard


Description	Pack qty.	Art No.
MODUL-EINSÄTZE WIPPTASTER MIT 1 BETÄTL..	10	5051
PUSH-BUTTON SWITCH HOTELC	10	5056
PB insert f. hotel card switch 10A, NO	10	505101
Switch push button for hotelcard	10	505102
PB insert for hotel card switch 2A, NO	10	505103
PB insert hotel card switch 2A, NO, NC	10	505201
MODUL-EINSÄTZE WIPPTASTER MIT 1 BETÄTL..	10	505203
PB insert hotel card switch 2A, ch.-over	10	505601



5051

Mechanical time switch

Description	Pack qty.	Art No.
INSERT TIMER 15 MIN.	1	2040
INSERT TIMER 120 MIN.	1	2041



2040





1600

Glow and neon lamp units

Description	Pack qty.	Art No.
NEON LAMP UNIT	10	1600
Neonlamp unit w/N-terminal, 230V/1m -grey	10	1675
GLOW LAMP UNIT 6 V	10	1676
Neon lamp unit Module inserts grey	10	160002
NEON LAMP UNIT 220V/0.4MA	10	160514
GMAG 230V/0,4MA ORA	10	167504
GLOW LAMP UNIT 6 V	10	167601
GLOW LAMP UNIT 6 V	10	167602
GLOW LAMP UNIT 6 V	10	167603



1680

LED units

Description	Pack qty.	Art No.
Series LED unit with N terminal	1	1680
LED GLAG 230V 1MA	10	1686
LED GLAG 12V-48V 0.2 – 0.9MA	10	1687
LED GLAG 230V 0.40MA	10	168601



1849

Accessories

Description	Pack qty.	Art No.
SCHUTZABDECKUNG	10	1849