



5101

Push button for light signal

Description	Pack qty.	Art No.
P/button and pilot lamp E10 inserts	10	5101
FLUSH MOM.CONT.SW./P.LAMP	10	510110



1601

Incandescent, neon and LED lamps

Description	Pack qty.	Art No.
NEON LAMP BULB E10 220V	100	1601
LED Lamp E10 White	60	1678
LED Lamp E14 White	20	1679
Incandescent lamp E14 Accessories	100	161003
INCANDESCENT LAMP E14	100	161013
LED-LEUCHTMITTEL E10 ROT	10	167801
LED-LEUCHTMITTEL E10 GELB	10	167802
LED-LEUCHTMITTEL E10 GRÜN	10	167803
LED-LEUCHTMITTEL E10 BLAU	10	167804
LED-LEUCHTMITTEL E14 ROT	10	167901
LED-LEUCHTMITTEL E14 GELB	10	167902
LED-LEUCHTMITTEL E14 GRÜN	10	167903
LED-LEUCHTMITTEL E14 BLAU	10	167904
Pilot lamp E14 Module inserts	10	513102



1220

Accessories

Description	Pack qty.	Art No.
Clear transp. cover for pilot lamp E14	10	1220
LENS PILOT LAMP E14 CLEAR	10	1230
LENS PILOT LAMP E14 RED	10	1231
LENS PILOT LAMP E14 GREEN	10	1232
BUTTON F. 5101, RED	10	1279
Clear transp. cover for pilot lamp E10	10	1280
LENS F.PILOT LAMP E10 RED	10	1281
LENS F.PILOT LAMPE10YELLO	10	1282
LENS F.PILOT LAMPE10GREEN	10	1283
SCREEN TPR RED	10	1289