

Inspire

	Page
White	3
Aurora silver	7
Noble bronze	10
Knight black	13
Elegant gold	16



WGCL111

Switches

Description	Pack qty.	Art No.
16AX 1G 1W switch	10	WGCL111
16AX 1G 2W switch	10	WGCL112
16AX 2G 1W switch	10	WGCL121
16AX 2G 2W switch	10	WGCL122
16AX 3G 1W switch	10	WGCL131
16AX 3G 2W switch	10	WGCL132
16AX 4G 1W switch	10	WGCL141
16AX 4G 2W switch	10	WGCL142
16AX 1G 1W switch w/fluorescence	10	WGCL111F
16AX 1G 2W switch w/fluorescence	10	WGCL112F
16AX 2G 1W switch w/fluorescence	10	WGCL121F
16AX 2G 2W switch w/fluorescence	10	WGCL122F
16AX 3G 1W switch w/fluorescence	10	WGCL131F
16AX 3G 2W switch w/fluorescence	10	WGCL132F
16AX 4G 1W switch w/fluorescence	10	WGCL141F
16AX 4G 2W switch w/fluorescence	10	WGCL142F
16AX 1G 1W round switch	10	WGCR111
16AX 1G 2W round switch	10	WGCR112
16AX 2G 1W round switch	10	WGCR121
16AX 2G 2W round switch	10	WGCR122
16AX 3G 1W round switch	10	WGCR131
16AX 3G 2W round switch	10	WGCR132
10AX 1G intermediate switch	10	WGCL113
10A 1G bell switch mark bell symbol	10	WGCL111B
10A 1G press switch mark "exit"	10	WGCL111E
10A 1G press switch	10	WGCL111P
10A 2G press switch	10	WGCL121P
10A 3G press switch	10	WGCL131P
10A 4G press switch	10	WGCL141P
10A 1G press round switch	10	WGCR111P
10A 2G press round switch	10	WGCR121P
10A 3G press round switch	10	WGCR131P



WGCL2D1N

Double-pole switched socket

Description	Pack qty.	Art No.
20AX 1G DP SWITCH W/ LED	10	WGCL2D1N
20AX 2G DP SWITCH W/ LED	10	WGCL2D2N
20AX 1G 2W DP SWITCH W/ LED	10	WGCL2D12N
16AX DND&MUR SWITCH W/ NEON (INDOOR)	10	WGCHDC
32A DP SWITCH	8	WGCR32D1
45A DP SWITCH	8	WGCR45D1



WGCS113S

13A single socket

Description	Pack qty.	Art No.
13A SINGLE SWITCHED SOCKET	10	WGCS113S
13A SINGLE SWITCHED SOCKET + USB	8	WGCS113SUSB

13A twin socket

Description	Pack qty.	Art No.
13A TWIN SWITCHED SOCKET	14	WGCS213S
13A TWIN SWITCHED SOCKET+2 USB	12	WGCS213SUBS



WGCS213S

15A and 16A socket outlets

Description	Pack qty.	Art No.
15A SINGLE SW SOCKET	10	WGCS115S
16A GERMAN SOCKET W/SHUTTER	8	WGCS116S
16A key tag switch - mechanical	6	WGCHKTM
16A key tag switch - rfid	6	WGCHKTRFID
16A SINGLE EURO-AMERICAN SOCKET	10	WGCS116EA
16A TWIN EURO-AMERICAN SOCKET	10	WGCS216EA



WGCS116S

Fan control

Description	Pack qty.	Art No.
250VA single fan control	6	WGCEFR250



WGCEFR250

Dimmer

Description	Pack qty.	Art No.
40-500W single dimmer	6	WGCEDR500



WGCEDR500



WGCEE1

Communication and data

Description	Pack qty.	Art No.
Emergency switch	8	WGCEE1
6W audio switch	6	WGCEA6
115/230V shaver socket	1	WGCHSR
hdmi+vga	10	WGCHHIVA
RCA+S-VIDEO socket	10	WGCHRCASV
STANDALONE USBX3 3.1A	8	WGCS3USB
USB+3.5mm audio socket	10	WGCHUSB35
RJ11 + RJ45 cat5e outlet	10	WGCT2RJRJ5
RJ11 + RJ45 cat6 outlet	10	WGCT2RJRJ6
RJ11 outlet (1mod)	10	WGCT1RJ
RJ11 outlet (2mod)	10	WGCT2RJ
RJ45 outlet cat6 (1mod)	10	WGCT1RJ6
RJ45 outlet cat6 (1mod) wo/symbol	10	WGCT1RJ6NM
RJ45 outlet cat5e (1mod)	10	WGCT1RJ5
RJ45 outlet cat6 (2mod)	10	WGCT2RJ6
RJ45 outlet cat6 (2mod) wo/symbol	10	WGCT2RJ6NM
RJ45 outlet cat6a (2mod)	10	WGCT2RJ6A
RJ45 outlet cat5e (2mod)	10	WGCT2RJ5
SMATV SOCKET	24	WGCTSMATV
TV + RJ45 cat5e outlet	10	WGCT2TVRJ5
TV outlet (1mod)	10	WGCT1TV
TV outlet f type (1mod)	10	WGCT1TVF



WGCC4

Horizontal frames

Description	Pack qty.	Art No.
2G multi-gang frame (horizontal)	5	WGCC2
3G multi-gang frame (horizontal)	5	WGCC3
4G multi-gang frame (horizontal)	5	WGCC4
5G multi-gang frame (horizontal)	5	WGCC5



WGCBP1

Blank plates

Description	Pack qty.	Art No.
Blank plate	20	WGCBP1
2 GANG FRAME	25	WGCC2
1G frame (square)	40	WGCC1S
1G frame (round)	40	WGCC1R

Vertical frames



WGCCV3

Description	Pack qty.	Art No.
2G frame (vertical)	5	WGCCV2
3G frame (vertical)	5	WGCCV3

Sockets

Description	Pack qty.	Art No.
10A 2 pin+2 pin socket	10	WGCS210U



WGCS210U



WGCXL111AS

Switches

Description	Pack qty.	Art No.
16AX 1G 1W switch;as	10	WGCXL111AS
16AX 1G 2W switch;as	10	WGCXL112AS
16AX 2G 1W switch;as	10	WGCXL121AS
16AX 2G 2W switch;as	10	WGCXL122AS
16AX 3G 1W switch;as	10	WGCXL131AS
16AX 3G 2W switch;as	10	WGCXL132AS
16AX 4G 1W switch;as	10	WGCXL141AS
16AX 4G 2W switch;as	10	WGCXL142AS
16AX 1G 1W switch w/fluorescence;as	10	WGCXL111FAS
16AX 1G 2W switch w/fluorescence;as	10	WGCXL112FAS
16AX 2G 1W switch w/fluorescence;as	10	WGCXL121FAS
16AX 2G 2W switch w/fluorescence;as	10	WGCXL122FAS
16AX 3G 1W switch w/fluorescence;as	10	WGCXL131FAS
16AX 3G 2W switch w/fluorescence;as	10	WGCXL132FAS
16AX 4G 1W switch w/fluorescence;as	10	WGCXL141FAS
16AX 4G 2W switch w/fluorescence;as	10	WGCXL142FAS
16AX 1G 1W round switch;as	10	WGCXR111AS
16AX 1G 2W round switch;as	10	WGCXR112AS
16AX 2G 1W round switch;as	10	WGCXR121AS
16AX 2G 2W round switch;as	10	WGCXR122AS
16AX 3G 1W round switch;as	10	WGCXR131AS
16AX 3G 2W round switch;as	10	WGCXR132AS
10AX 1G intermediate switch;as	10	WGCXL113AS
10A 1G bell switch mark bell symbol;as	10	WGCXL111BAS
10A 1G press switch mark "exit";as	10	WGCXL111EAS
10A 1G press switch;as	10	WGCXL111PAS
10A 2G press switch;as	10	WGCXL121PAS
10A 3G press switch;as	10	WGCXL131PAS
10A 4G press switch;as	10	WGCXL141PAS
10A 1G press round switch;as	10	WGCXR111PAS
10A 2G press round switch;as	10	WGCXR121PAS
10A 3G press round switch;as	10	WGCXR131PAS
20AX 1G DP SWITCH W/ LED, Aurora Silver	10	WGCXL2D1NAS
20AX 2G DP SWITCH W/ LED, Aurora Silver	10	WGCXL2D2NAS
20AX 1G 2W DP SWITCH W/ LED, AS	10	WGCXL2D12NAS
16AX DND&MUR SWITCH W/ NEON (INDOOR), AS	10	WGCXHDCAAS

Control unit

Description	Pack qty.	Art No.
32A DP SWITCH	8	WGCXR32D1AS
45A DP SWITCH	8	WGCXR45D1AS

Sockets

Description	Pack qty.	Art No.
10A 2 pin+2 pin socket;as	10	WGCXS210UAS



WGCXS113SAS

13A single socket

Description	Pack qty.	Art No.
13A SINGLE SWITCHED SOCKET, AS	10	WGCXS113SAS
13A SINGLE SWITCHED SOCKET + USB, AS	8	WGCXS113SUSBAS

13A twin socket

Description	Pack qty.	Art No.
13A TWIN SWITCHED SOCKET, AS	14	WGCXS213SAS
13A TWIN SWITCHED SOCKET+2 USB, AS	12	WGCXS213SUSB AS



WGCXS213SAS

15A and 16A socket outlets

Description	Pack qty.	Art No.
15A SINGLE SW SOCKET, Aurora Silver	10	WGCXS115SAS
16A GERMAN SOCKET W/SHUTTER, AS	8	WGCXS116SAS
16A key tag switch - mechanical;as	6	WGCXHKTMS
16A key tag switch - rfid;as	6	WGCXHKTRFIDA S
16A SINGLE EURO-AMERICAN SOCKET, AS	10	WGCXS116EAS
16A TWIN EURO-AMERICAN SOCKET, AS	10	WGCXS216EAS



WGCXS116SAS

Fan control

Description	Pack qty.	Art No.
250VA single fan control;as	6	WGCXEFR250AS

Dimmer

Description	Pack qty.	Art No.
40-500W single dimmer;as	6	WGCXEDR500AS

Communication and data

Description	Pack qty.	Art No.
Emergency switch;as	8	WGCXEE1AS
6W audio switch;as	6	WGCXEA6AS
115/230V shaver socket;as	1	WGCXHRSRAS
hdmi+vga;as	10	WGCXHHIVAAS
RCA+S-VIDEO socket;as	10	WGCXHRCASVAS
STANDALONE USBX3 4.2A, AS	8	WGCXS3USBAS
USB+3.5mm audio socket;as	10	WGCXHUSB35AS
RJ11 + RJ45 cat5e outlet;as	10	WGCXT2RJRJ5A S
RJ11 + RJ45 cat6 outlet;as	10	WGCXT2RJRJ6A S
RJ11 outlet (1mod);as	10	WGCXT1RJAS
RJ11 outlet (2mod);as	10	WGCXT2RJAS
RJ45 outlet cat6 (1mod);as	10	WGCXT1RJ6AS
RJ45 outlet cat6 (1mod) wo/symbol;as	10	WGCXT1RJ6NMA S
RJ45 outlet cat5e (1mod);as	10	WGCXT1RJ5AS
RJ45 outlet cat6 (2mod);as	10	WGCXT2RJ6AS
RJ45 outlet cat6 (2mod) wo/symbol;as	10	WGCXT2RJ6NMA S
RJ45 outlet cat5e (2mod);as	10	WGCXT2RJ5AS
TV + RJ45 cat5e outlet;as	10	WGCXT2TVRJ5A S
TV outlet (1mod);as	10	WGCXT1TVAS
TV outlet f type (1mod);as	10	WGCXT1TVFAS



WGCXHRSRAS

Horizontal frames

Description	Pack qty.	Art No.
2G multi-gang frame (horizontal);as	5	WGCH2AS
3G multi-gang frame (horizontal);as	5	WGCH3AS
4G multi-gang frame (horizontal);as	5	WGCH4AS
5G multi-gang frame (horizontal);as	5	WGCH5AS

Blank plates

Description	Pack qty.	Art No.
Blank plate;as	20	WGCXBP1AS
2 GANG FRAME, Aurora Silver	25	WGCC2AS
1G frame (square);as	40	WGCC1SAS
1G frame (round);as	40	WGCC1RAS

Vertical frames

Description	Pack qty.	Art No.
2G frame (vertical);as	5	WGCCV2AS
3G frame (vertical);as	5	WGCCV3AS

Switches

Description	Pack qty.	Art No.
16AX 1G 1W switch;nb	10	WGCXL111NB
16AX 1G 2W switch;nb	10	WGCXL112NB
16AX 2G 1W switch;nb	10	WGCXL121NB
16AX 2G 2W switch;nb	10	WGCXL122NB
16AX 3G 1W switch;nb	10	WGCXL131NB
16AX 3G 2W switch;nb	10	WGCXL132NB
16AX 4G 1W switch;nb	10	WGCXL141NB
16AX 4G 2W switch;nb	10	WGCXL142NB
16AX 1G 1W switch w/fluorescence;nb	10	WGCXL111FNB
16AX 1G 2W switch w/fluorescence;nb	10	WGCXL112FNB
16AX 2G 1W switch w/fluorescence;nb	10	WGCXL121FNB
16AX 2G 2W switch w/fluorescence;nb	10	WGCXL122FNB
16AX 3G 1W switch w/fluorescence;nb	10	WGCXL131FNB
16AX 3G 2W switch w/fluorescence;nb	10	WGCXL132FNB
16AX 4G 1W switch w/fluorescence;nb	10	WGCXL141FNB
16AX 4G 2W switch w/fluorescence;nb	10	WGCXL142FNB
16AX 1G 1W round switch;nb	10	WGCXR111NB
16AX 1G 2W round switch;nb	10	WGCXR112NB
16AX 2G 1W round switch;nb	10	WGCXR121NB
16AX 2G 2W round switch;nb	10	WGCXR122NB
16AX 3G 1W round switch;nb	10	WGCXR131NB
16AX 3G 2W round switch;nb	10	WGCXR132NB
10AX 1G intermediate switch;nb	10	WGCXL113NB
10A 1G bell switch mark bell symbol;nb	10	WGCXL111BNB
10A 1G press switch mark "exit";nb	10	WGCXL111ENB
10A 1G press switch;nb	10	WGCXL111PNB
10A 2G press switch;nb	10	WGCXL121PNB
10A 3G press switch;nb	10	WGCXL131PNB
10A 4G press switch;nb	10	WGCXL141PNB
10A 1G press round switch;nb	10	WGCXR111PNB
10A 2G press round switch;nb	10	WGCXR121PNB
10A 3G press round switch;nb	10	WGCXR131PNB
20AX 1G DP SWITCH W/ LED, Noble Bronze	10	WGCXL2D1NNB
20AX 2G DP SWITCH W/ LED, Noble Bronze	10	WGCXL2D2NNB
20AX 1G 2W DP SWITCH W/ LED, NB	10	WGCXL2D12NNB
16AX DND&MUR SWITCH W/ NEON (INDOOR), NB	10	WGCXHDCNB



WGCXL111NB

Control unit

Description	Pack qty.	Art No.
32A DP SWITCH	8	WGCXR32D1NB
45A DP SWITCH	8	WGCXR45D1NB

Sockets

Description	Pack qty.	Art No.
10A 2 pin+2 pin socket;nb	10	WGCXS210UNB



WGCXS210UNB



WGCXS113SNB

13A single socket

Description	Pack qty.	Art No.
13A SINGLE SWITCHED SOCKET, NB	10	WGCXS113SNB
13A SINGLE SWITCHED SOCKET + USB, NB	8	WGCXS113SUSB NB



WGCXS213SNB

13A twin socket

Description	Pack qty.	Art No.
13A TWIN SWITCHED SOCKET, NB	14	WGCXS213SNB
13A TWIN SWITCHED SOCKET+2 USB, NB	12	WGCXS213SUSB NB



WGCXS116SNB

15A and 16A socket outlets

Description	Pack qty.	Art No.
15A SINGLE SW SOCKET, Noble Bronze	10	WGCXS115SNB
16A GERMAN SOCKET W/SHUTTER, NB	8	WGCXS116SNB
16A key tag switch - mechanical;nb	6	WGCXHKTMNB
16A key tag switch - rfid;nb	6	WGCXHKTRFIDNB
16A SINGLE EURO-AMERICAN SOCKET, NB	10	WGCXS116EANB
16A TWIN EURO-AMERICAN SOCKET, NB	10	WGCXS216EANB



WGCXEFR250NB

Fan control

Description	Pack qty.	Art No.
250VA single fan control;nb	6	WGCXEFR250NB



WGCXEDR500NB

Dimmer

Description	Pack qty.	Art No.
40-500W single dimmer;nb	6	WGCXEDR500NB

Communication and data

Description	Pack qty.	Art No.
Emergency switch;nb	8	WGCXEE1NB
6W audio switch;nb	6	WGCXEA6NB
115/230V shaver socket;nb	1	WGCXH5SRNB
hdmi+vga;nb	10	WGCXHHIVANB
RCA+S-VIDEO socket;nb	10	WGCXHRCASVNB
STANDALONE USBX3 4.2A, NB	8	WGCXS3USBNB
USB+3.5mm audio socket;nb	10	WGCXHUSB35NB
RJ11 + RJ45 cat5e outlet;nb	10	WGCXT2RJRJ5NB
RJ11 + RJ45 cat6 outlet;nb	10	WGCXT2RJRJ6NB
RJ11 outlet (1mod);nb	10	WGCXT1RJNB
RJ11 outlet (2mod);nb	10	WGCXT2RJNB
RJ45 outlet cat6 (1mod);nb	10	WGCXT1RJ6NB
RJ45 outlet cat6 (1mod) wo/symbol;nb	10	WGCXT1RJ6NMNB
RJ45 outlet cat5e (1mod);nb	10	WGCXT1RJ5NB
RJ45 outlet cat6 (2mod);nb	10	WGCXT2RJ6NB
RJ45 outlet cat6 (2mod) wo/symbol;nb	10	WGCXT2RJ6NMNB
RJ45 outlet cat5e (2mod);nb	10	WGCXT2RJ5NB
TV + RJ45 cat5e outlet;nb	10	WGCXT2TVRJ5NB
TV outlet (1mod);nb	10	WGCXT1TVNB
TV outlet f type (1mod);nb	10	WGCXT1TVFNB



WGCXEE1NB

Horizontal frames

Description	Pack qty.	Art No.
2G multi-gang frame (horizontal);nb	5	WGCCCH2NB
3G multi-gang frame (horizontal);nb	5	WGCCCH3NB
4G multi-gang frame (horizontal);nb	5	WGCCCH4NB
5G multi-gang frame (horizontal);nb	5	WGCCCH5NB



WGCCCH2NB

Blank plates

Description	Pack qty.	Art No.
Blank plate;nb	20	WGCXBP1NB
2 GANG FRAME, Noble Bronze	25	WGCC2NB
1G frame (square);nb	40	WGCC1SNB
1G frame (round);nb	40	WGCC1RNB



WGCXBP1NB

Vertical frames

Description	Pack qty.	Art No.
2G frame (vertical);nb	5	WGCCV2NB
3G frame (vertical);nb	5	WGCCV3NB



WGCXL111KB

Switches

Description	Pack qty.	Art No.
16AX 1G 1W switch;kb	10	WGCXL111KB
16AX 1G 2W switch;kb	10	WGCXL112KB
16AX 2G 1W switch;kb	10	WGCXL121KB
16AX 2G 2W switch;kb	10	WGCXL122KB
16AX 3G 1W switch;kb	10	WGCXL131KB
16AX 3G 2W switch;kb	10	WGCXL132KB
16AX 4G 1W switch;kb	10	WGCXL141KB
16AX 4G 2W switch;kb	10	WGCXL142KB
16AX 1G 1W switch w/fluorescence;kb	10	WGCXL111FKB
16AX 1G 2W switch w/fluorescence;kb	10	WGCXL112FKB
16AX 2G 1W switch w/fluorescence;kb	10	WGCXL121FKB
16AX 2G 2W switch w/fluorescence;kb	10	WGCXL122FKB
16AX 3G 1W switch w/fluorescence;kb	10	WGCXL131FKB
16AX 3G 2W switch w/fluorescence;kb	10	WGCXL132FKB
16AX 4G 1W switch w/fluorescence;kb	10	WGCXL141FKB
16AX 4G 2W switch w/fluorescence;kb	10	WGCXL142FKB
16AX 1G 1W round switch;kb	10	WGCXR111KB
16AX 1G 2W round switch;kb	10	WGCXR112KB
16AX 2G 1W round switch;kb	10	WGCXR121KB
16AX 2G 2W round switch;kb	10	WGCXR122KB
16AX 3G 1W round switch;kb	10	WGCXR131KB
16AX 3G 2W round switch;kb	10	WGCXR132KB
10AX 1G intermediate switch;kb	10	WGCXL113KB
10A 1G bell switch mark bell symbol;kb	10	WGCXL111BKB
10A 1G press switch mark "exit";kb	10	WGCXL111EKB
10A 1G press switch;kb	10	WGCXL111PKB
10A 2G press switch;kb	10	WGCXL121PKB
10A 3G press switch;kb	10	WGCXL131PKB
10A 4G press switch;kb	10	WGCXL141PKB
10A 1G press round switch;kb	10	WGCXR111PKB
10A 2G press round switch;kb	10	WGCXR121PKB
10A 3G press round switch;kb	10	WGCXR131PKB
20AX 1G DP SWITCH W/ LED, Knight black	10	WGCXL2D1NKB
20AX 2G DP SWITCH W/ LED, Knight black	10	WGCXL2D2NKB
20AX 1G 2W DP SWITCH W/ LED, KB	10	WGCXL2D12NKB
16AX DND&MUR SWITCH W/ NEON (INDOOR), KB	10	WGCXHDCKB

Control unit

Description	Pack qty.	Art No.
32A DP SWITCH	8	WGCXR32D1KB
45A DP SWITCH	8	WGCXR45D1KB



WGCXS210UKB

Sockets

Description	Pack qty.	Art No.
10A 2 pin+2 pin socket;kb	10	WGCXS210UKB

13A single socket

Description	Pack qty.	Art No.
13A SINGLE SWITCHED SOCKET, KB	10	WGCXS113SKB
13A SINGLE SWITCHED SOCKET + USB, KB	8	WGCXS113SUSB KB



WGCXS113SKB

13A twin socket

Description	Pack qty.	Art No.
13A TWIN SWITCHED SOCKET, KB	14	WGCXS213SKB
13A TWIN SWITCHED SOCKET+2 USB, KB	12	WGCXS213SUSB KB



WGCXS213SKB

15A and 16A socket outlets

Description	Pack qty.	Art No.
15A SINGLE SW SOCKET, Knight black	10	WGCXS115SKB
16A GERMAN SOCKET W/SHUTTER, KB	8	WGCXS116SKB
16A key tag switch - mechanical;kb	6	WGCXHKTMKB
16A key tag switch - rfid;kb	6	WGCXHKTRFIDKB
16A SINGLE EURO-AMERICAN SOCKET, KB	10	WGCXS116EAKB
16A TWIN EURO-AMERICAN SOCKET, KB	10	WGCXS216EAKB



WGCXS116SKB

Fan control

Description	Pack qty.	Art No.
250VA single fan control;kb	6	WGCXEFR250KB



WGCXEFR250KB

Dimmer

Description	Pack qty.	Art No.
40-500W single dimmer;kb	6	WGCXEDR500KB



WGCXEDR500KB



WGCXEE1KB

Communication and data

Description	Pack qty.	Art No.
Emergency switch;kb	8	WGCXEE1KB
6W audio switch;kb	6	WGCXEA6KB
115/230V shaver socket;kb	1	WGCXHSRKB
hdmi+vga;kb	10	WGCXHHIVAKB
RCA+S-VIDEO socket;kb	10	WGCXHRCASVKB
STANDALONE USBX3 4.2A, KB	8	WGCXS3USBKB
USB+3.5mm audio socket;kb	10	WGCXHUSB35KB
RJ11 + RJ45 cat5e outlet;kb	10	WGCXT2RJRJ5KB
RJ11 + RJ45 cat6 outlet;kb	10	WGCXT2RJRJ6KB
RJ11 outlet (1mod);kb	10	WGCXT1RJKB
RJ11 outlet (2mod);kb	10	WGCXT2RJKB
RJ45 outlet cat6 (1mod);kb	10	WGCXT1RJ6KB
RJ45 outlet cat6 (1mod) wo/symbol;kb	10	WGCXT1RJ6NMKB
RJ45 outlet cat5e (1mod);kb	10	WGCXT1RJ5KB
RJ45 outlet cat6 (2mod);kb	10	WGCXT2RJ6KB
RJ45 outlet cat6 (2mod) wo/symbol;kb	10	WGCXT2RJ6NMKB
RJ45 outlet cat5e (2mod);kb	10	WGCXT2RJ5KB
TV + RJ45 cat5e outlet;kb	10	WGCXT2TVRJ5KB
TV outlet (1mod);kb	10	WGCXT1TVKB
TV outlet f type (1mod);kb	10	WGCXT1TVFKB



WGCCH2KB

Horizontal frames

Description	Pack qty.	Art No.
2G multi-gang frame (horizontal);kb	5	WGCCH2KB
3G multi-gang frame (horizontal);kb	5	WGCCH3KB
4G multi-gang frame (horizontal);kb	5	WGCCH4KB
5G multi-gang frame (horizontal);kb	5	WGCCH5KB



WGCXBP1KB

Blank plates

Description	Pack qty.	Art No.
Blank plate;kb	20	WGCXBP1KB
2 GANG FRAME, Knight black	25	WGCC2KB
1G frame (square);kb	40	WGCC1SKB
1G frame (round);kb	40	WGCC1RKB

Vertical frames

Description	Pack qty.	Art No.
2G frame (vertical);kb	5	WGCCV2KB
3G frame (vertical);kb	5	WGCCV3KB

Switches

WGCXL111EG

Description	Pack qty.	Art No.
16AX 1G 1W switch;eg	10	WGCXL111EG
16AX 1G 2W switch;eg	10	WGCXL112EG
16AX 2G 1W switch;eg	10	WGCXL121EG
16AX 2G 2W switch;eg	10	WGCXL122EG
16AX 3G 1W switch;eg	10	WGCXL131EG
16AX 3G 2W switch;eg	10	WGCXL132EG
16AX 4G 1W switch;eg	10	WGCXL141EG
16AX 4G 2W switch;eg	10	WGCXL142EG
16AX 1G 1W switch w/fluorescence;eg	10	WGCXL111FEG
16AX 1G 2W switch w/fluorescence;eg	10	WGCXL112FEG
16AX 2G 1W switch w/fluorescence;eg	10	WGCXL121FEG
16AX 2G 2W switch w/fluorescence;eg	10	WGCXL122FEG
16AX 3G 1W switch w/fluorescence;eg	10	WGCXL131FEG
16AX 3G 2W switch w/fluorescence;eg	10	WGCXL132FEG
16AX 4G 1W switch w/fluorescence;eg	10	WGCXL141FEG
16AX 4G 2W switch w/fluorescence;eg	10	WGCXL142FEG
16AX 1G 1W round switch;eg	10	WGCXR111EG
16AX 1G 2W round switch;eg	10	WGCXR112EG
16AX 2G 1W round switch;eg	10	WGCXR121EG
16AX 2G 2W round switch;eg	10	WGCXR122EG
16AX 3G 1W round switch;eg	10	WGCXR131EG
16AX 3G 2W round switch;eg	10	WGCXR132EG
10AX 1G intermediate switch;eg	10	WGCXL113EG
10A 1G bell switch mark bell symbol;eg	10	WGCXL111BEG
10A 1G press switch mark "exit";eg	10	WGCXL111EEG
10A 1G press switch;eg	10	WGCXL111PEG
10A 2G press switch;eg	10	WGCXL121PEG
10A 3G press switch;eg	10	WGCXL131PEG
10A 4G press switch;eg	10	WGCXL141PEG
10A 1G press round switch;eg	10	WGCXR111PEG
10A 2G press round switch;eg	10	WGCXR121PEG
10A 3G press round switch;eg	10	WGCXR131PEG
20AX 1G DP SWITCH W/ LED, Elegant Gold	10	WGCXL2D1NEG
20AX 2G DP SWITCH W/ LED, Elegant Gold	10	WGCXL2D2NEG
20AX 1G 2W DP SWITCH W/ LED, EG	10	WGCXL2D12NEG
16AX DND&MUR SWITCH W/ NEON (INDOOR), EG	10	WGCXHDCEG

Control unit

Description	Pack qty.	Art No.
32A DP SWITCH	8	WGCXR32D1EG
45A DP SWITCH	8	WGCXR45D1EG

Sockets

Description	Pack qty.	Art No.
10A 2 pin+2 pin socket;eg	10	WGCXS210UEG

13A single socket

Description	Pack qty.	Art No.
13A SINGLE SWITCHED SOCKET, EG	10	WGCXS113SEG
13A SINGLE SWITCHED SOCKET + USB, EG	8	WGCXS113SUSB EG



WGCXS113SEG

**13A twin socket**

Description	Pack qty.	Art No.
13A TWIN SWITCHED SOCKET, EG	14	WGCXS213SEG
13A TWIN SWITCHED SOCKET+2 USB, EG	12	WGCXS213SUBEG

WGCXS213SEG



WGCXS116SEG

15A and 16A socket outlets

Description	Pack qty.	Art No.
15A SINGLE SW SOCKET, Elegant Gold	10	WGCXS115SEG
16A GERMAN SOCKET W/SHUTTER, EG	8	WGCXS116SEG
16A key tag switch - mechanical;eg	6	WGCXHKTMEG
16A key tag switch - rfid;eg	6	WGCXHKTRFIDEG
16A SINGLE EURO-AMERICAN SOCKET, EG	10	WGCXS116EAE
16A TWIN EURO-AMERICAN SOCKET, EG	10	WGCXS216EAE

Fan control

Description	Pack qty.	Art No.
250VA single fan control;eg	6	WGCXEFR250EG

Dimmer

Description	Pack qty.	Art No.
40-500W single dimmer;eg	6	WGCXEDR500EG



WGCXHSREG

Communication and data

Description	Pack qty.	Art No.
Emergency switch;eg	8	WGCXEE1EG
6W audio switch;eg	6	WGCXEA6EG
115/230V shaver socket;eg	1	WGCXHSREG
hdmi+vga;eg	10	WGCXHIVAEG
RCA+S-VIDEO socket;eg	10	WGCXHRCASVEG
STANDALONE USBX3 4.2A, EG	8	WGCXS3USBEG
USB+3.5mm audio socket;eg	10	WGCXHUSB35EG
RJ11 + RJ45 cat5e outlet;eg	10	WGCXT2RJ5EG
RJ11 + RJ45 cat6 outlet;eg	10	WGCXT2RJ6EG
RJ11 outlet (1mod);eg	10	WGCXT1RJEG
RJ11 outlet (2mod);eg	10	WGCXT2RJEG
RJ45 outlet cat6 (1mod);eg	10	WGCXT1RJ6EG
RJ45 outlet cat6 (1mod) wo/symbol;eg	10	WGCXT1RJ6NMEG
RJ45 outlet cat5e (1mod);eg	10	WGCXT1RJ5EG
RJ45 outlet cat6 (2mod);eg	10	WGCXT2RJ6EG
RJ45 outlet cat6 (2mod) wo/symbol;eg	10	WGCXT2RJ6NMEG
RJ45 outlet cat5e (2mod);eg	10	WGCXT2RJ5EG
TV + RJ45 cat5e outlet;eg	10	WGCXT2TVRJ5EG
TV outlet (1mod);eg	10	WGCXT1TVEG
TV outlet f type (1mod);eg	10	WGCXT1TVFEG

Horizontal frames

Description	Pack qty.	Art No.
2G multi-gang frame (horizontal);eg	5	WGCH2EG
3G multi-gang frame (horizontal);eg	5	WGCH3EG
4G multi-gang frame (horizontal);eg	5	WGCH4EG
5G multi-gang frame (horizontal);eg	5	WGCH5EG

Blank plates

Description	Pack qty.	Art No.
Blank plate;eg	20	WGCXBP1EG
2 GANG FRAME, Elegant Gold	25	WGCC2EG
1G frame (square);eg	40	WGCC1SEG
1G frame (round);eg	40	WGCC1REG

Vertical frames

Description	Pack qty.	Art No.
2G frame (vertical);eg	5	WGCCV2EG
3G frame (vertical);eg	5	WGCCV3EG